



- 1) pull diverter knob # 092062031-ff
 - 2) a 3 mm boreholing becomes visible at the lock nut # 092110035-ff
 - 3) insert a steel mandrel (standard tool) and turn careful anti-clockwise until lock nut is complete loose
 - 4) pull out complete unit with diverter
 - 5) clean & grease diverter and insert back into body and tighten lock nut carefully
- or if needed
- 5) disassemble (unscrew) diverter from handle
 - 6) replace diverter # 90310903200-ff and assemble completely backwards

