
















DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
BG Brugsanvisning / Monteringsvejledning
DK Mode d'emploi / Instructions de montage
FR Gebruiksaanwijzing / Handleiding
NL Bruksanvisning / Montasjehandleiding
NO Instruksjon for bruk / Manual de instalación
PT Návod k použití / Montážní návod
CZ Használati útmutató / Szerelési útmutató
HU Bruksanvisning / Monteringsanvisning
SV Modo de empleo / Instrucciones de montaje
ES Руководство пользователя /
RU Инструкция по монтажу
IT Istruzioni per l'installazione / Istruzioni per l'uso
SK Montážny návod / Návod na použitie




0015105000001









- 01 0018165000001
- 02 0018590800001
- 03 0018360800001
- 04 0018310800001
- 05 0018605000001



Schlösser Armaturen GmbH & Co. KG
Im Dohm 3
57462 Olpe
GERMANY
www.schloesser-armaturen.de
info@schloesser-armaturen.de

