


















04 24 04 187 00



	Chrom	04 24 04 187 00-00
	Platin gebürstet	04 24 04 187 00-06
	Platin	04 24 04 187 00-08
	Messing (23kt Gold)	04 24 04 187 00-09
	Dark Brass matt	04 24 04 187 00-16
	Dark Bronze matt	04 24 04 187 00-17
	Dark Chrome	04 24 04 187 00-19
	Light Gold gebürstet	04 24 04 187 00-27
	Messing gebürstet (23kt Gold)	04 24 04 187 00-28
	Schwarz matt	04 24 04 187 00-33
	Dark Brass gebürstet	04 24 04 187 00-39
	Bronze gebürstet	04 24 04 187 00-42
	Champagne gebürstet (22kt Gold)	04 24 04 187 00-46
	Champagne (22kt Gold)	04 24 04 187 00-47
	Cyprum	04 24 04 187 00-49
	Chrom gebürstet	04 24 04 187 00-93
	Dark Platinum gebürstet	04 24 04 187 00-99



Bogen 20° Ø 29 mm - Chrom

ERSATZTEILE

04 24 04 187 00



Bogen 20° Ø 29 mm - Chrom

ERSATZTEILE

04 24 04 187 00