







DIN EN 806
DIN EN 1717
DIN 1988
Global Standards



- ⓓ Montage- und Bedienanleitung
- Ⓒᵀ 安裝及操作指南
- Ⓒᶻ Návod k instalaci a k použití
- Ⓔ Instrucciones de montaje y de manejo
- Ⓔᵀ Paigaldamine ja kasutamine
- Ⓕ Instructions de montage et d'utilisation
- Ⓖᵀ Installation and operating instructions
- Ⓖᵀ ὈΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗΣ
- Ⓕ Szerelési és használati utasítás
- Ⓘ Istruzioni di montaggio e per l'uso
- Ⓕᵀ Montavimo ir naudojimo instrukcija
- Ⓕᵀ Montāžas un lietošanas instrukcija
- Ⓖᵀ Montagehandleiding en Gebruiksaanwijzing
- Ⓕᵀ Instrukcja montażu i obsługi
- Ⓕᵀ Instrucțiuni de montaj și utilizare
- Ⓔᵀ Руководство по монтажу и эксплуатации
- Ⓕᵀ Návod na montáž a obsluhu
- Ⓕᵀ Navodila za montažo in uporabo
- Ⓕᵀ Інструкція по монтажу та експлуатації
- Ⓕᵀ تعليمات التركيب والتشغيل









9 62 728/02


Kludi GmbH & Co. KG
Postfach 25 60
D-58685 Menden
Am Vogelsang 31-33
D-58706 Menden

Telefon: (D) +49 (0) 23 73 / 904-0
Telefax: (D) +49 (0) 23 73 / 904-4 65
E-Mail: info.de@kludi.com
Internet: www.kludi.com


KLUDI




6.




7.




8.




9.




10.




11.




12.



13.



15.



14.

