







04 28 22 173 00



	Chrom	04 28 22 173 00-00
	Gold (23,9kt)	04 28 22 173 00-01
	Platin gebürstet	04 28 22 173 00-06
	Platin	04 28 22 173 00-08
	Messing (23kt Gold)	04 28 22 173 00-09



Auslauf 170 x 35 x 9 mm - Chrom

ERSATZTEILE

04 28 22 173 00



Auslauf 170 x 35 x 9 mm - Chrom

ERSATZTEILE

04 28 22 173 00