









04 12 11 094 10



	Chrom	04 12 11 094 10-00
	Platin gebürstet	04 12 11 094 10-06
	Platin	04 12 11 094 10-08
	Messing (23kt Gold)	04 12 11 094 10-09
	Dark Chrome	04 12 11 094 10-19
	Bronze gebürstet	04 12 11 094 10-42
	Chrom gebürstet	04 12 11 094 10-93
	Dark Platinum gebürstet	04 12 11 094 10-99



Spülbrause - Chrom

ERSATZTEILE

04 12 11 094 10




Spülbrause - Chrom

ERSATZTEILE

04 12 11 094 10

04 12 11 094 10

Ersatzteile für die
anderen
Oberflächenvarianten
finden Sie hier: Platin
gebürstet



Ersatzteilstückliste

Nr.	Artikelnummer	Benennung	Verbaumenge	Lieferzeit
1	12 864 970-00	Reparaturset - Chrom	1,00	10
2	90 12 08 019 00-00	Brause für Spülbrausen Brausekopf Ø 26 x 32 mm - Chrom	1,00	10